362 CHAPTER FIFTEEN

- 3. Remove the headlight lower mounting bolts (Figure 10).
- 4. Remove the bolts securing the front bumper to the frame.
- 5. Remove the front bumper (B, **Figure 9**).
- 6. Install by reversing the preceding removal steps.

CENTER MUD GUARDS (FE AND TE MODELS)

Removal/Installation

- 1. Remove the recoil starter cover as described in this chapter.
- 2. Remove the footpeg (A, **Figure 11**).
- 3. On the right side, remove the socket bolt (B, **Figure 11**).
- 4. Remove the retaining clips.
- 5. Remove the center mud guard (C, Figure 11).
- 6. Reverse the removal steps to install the center mud guard.

FRONT MUD GUARDS


Removal/Installation


- 1. On FE/TE models, remove the center mud guard as described in this chapter.
- 2. Remove the retaining clips at the front of the mud guard (Figure 12).
- 3. Remove the socket bolt (A, Figure 13).
- 4. Remove the remaining retaining clips, then remove the front mud guard (B, **Figure 13**).
- 5. Reverse the removal steps to install the front mud guard.

REAR MUD GUARDS (FM AND TM MODELS)

Removal/Installation

- 1. Remove the recoil starter cover as described in this chapter.
- 2. On the right side, remove the socket bolts at the inner corner and at the center of the mud guard.
- 3. On the left side, remove the socket bolt.
- 4. Remove the retaining clips, then remove the rear mud guard.
- 5. Reverse the removal steps to install the rear mud guard.







Copyright of Honda TRX350 RANCHER, 2000-2006 is the property of Penton Media, Inc. ("Clymer") and its content may not be copied or emailed to multiple sites or posted to a listserv without the copyright holder's express written permission. However, users may print, download, or email articles for individual use.